



## BACKFLOW INSPECTION PROCEDURES

### INSTALLATION – TESTING – INSPECTION

All irrigation/lawn sprinkler systems, hot tubs, booster pumps, and auxiliary water systems shall be protected against anti-siphon by the installation of an approved backflow device. Permit applications can be obtained at City Hall, 680 Greenwood Street or at [www.junctioncityoregon.gov](http://www.junctioncityoregon.gov)

### PROCEDURES

- ☐ **Step 1 – Request a preliminary inspection with Public Works Staff to review the type of backflow device best suited for your use. Call 541.998.3125 to schedule.**
- ☐ **Step 2 – Obtain a Plumbing permit (your contractor may do this for you)  
Applications are available at City Hall or [www.junctioncityoregon.gov](http://www.junctioncityoregon.gov)**
- ☐ **Step 3 – After installation have the device tested by a certified backflow device tester.  
Test results must be on site for inspections (see information about Certified Testers)**
- ☐ **Step 4 – Call for inspections. There are 2 inspections necessary:**
  - ⇒ **Call for a Public Works inspection at 541.998.3125**
  - ⇒ **Call Clair Company at 541.758.1302 or 1.800.383.8855**

*It is recommended that you retain the permit, test results and inspection records. Most backflow devices are required to be re-tested annually.*

### [Certified Backflow Assembly Testers of Oregon](#)

Backflow Assembly Testers are required to obtain licensing through the Construction Contractors Board (CCB) or the Landscape Contractors Board (LCB) if they provide their services for a fee. Call CCB at 1.503.378.4621 or LCB at 1.503.986.6561 to verify licensing.

**Current testers in Lane County can be found online @:**

<https://yourwater.oregon.gov/backflow.php?county=Lane>